














| NO. | Parts List | Q'ty | | | | | |
|-----|---|------|---|--|--|---|--|
| ① |  | X1 |  |  <p>The lever must be always to the front</p> |  |  | |
| ② |  | X1 | | | | | |
| ③ |  | X1 | |  <p>The lever must be always to the front</p> | |  | |
| ④ |  | X1 | | | | | |
| ⑤ |  | X1 | | | | | |
| ⑥ |  M8X17 | X1 | | | | | |
| ⑦ |  M8X20 | X1 | | | | | |